

Installation Instructions for Handy Spray.

Kit Includes

1 Sprayer with Hose, 1 three way valve,
1 Wall Bracket with screws, 2 Flat rubber washers,
1 O-ring washer, Teflon Tape.

Required

Phillips Screw Driver.
Flexible Supply Line in some cases. *Read Step 1 to determine.*

Important

Handy Tighten ONLY. Use Teflon tape before screwing on any component to ensure complete sealing. Change sprayer every 12 months. Order replacement sprayer at www.handyspray.com



Step 1. Make sure that the supply line to flush tank is a flexible supply line. If supply line is hard metal supply line or it is very old then you need to purchase a new flexible supply line from Hardware store. Turn off water to flush tank and flush tank to empty.

Step 2. Turn Unscrew existing supply line from tank nut. (Important: If you are using a new supply line the screw new supply line into the tank water shut-off valve and leave tank nut side unscrewed.)

Step 3. Insert flat washer into 3 way valve nut. **3B** Screw 3-way valve underneath flush tank and hand tighten. Use teflon tape.



Step 4. If supply line has a dome shaped rubber washer insert additional O ring washer into supply line tank nut.



Step 5. Screw supply line to underneath 3-way valve. Use Teflon tape. Hand Tighten.

Step 6. Screw on main hose and spray hose and spray to flow control valve and tighten.

Step 7. Turn on water and check for leaks and retighten as needed. Install wall bracket using screws and anchors provided.

Etooti Inc and Handy Spray are not responsible in anyway for inaccurate installation or defective plumbing.

Handy Spray is a product of Etooti Inc. Toll Free 866 4 MY WASH



6