

# Installation Instructions Classic Series

## Parts included in

Complete pre-assembled kit  
Mounting Bracket, Anchors, Double Sided Tape

## Required

Adjustable wrench  
Flush tank flexible hose with 7/8" nut & 3/8" nut



### Step 1

Turn off water supply by turning the flush tank shut-off valve.

Flush to make sure flush tank is empty and water has stopped filling.



### Step 2

Remove the pipe connecting the shut off to the tank valve



### Step 3

Screw the tank nut to the nut underneath the Toilet Flush Tank. The 3/4" brass nut can be screwed to the shut-off valve.



### Step 4

Install the Wall Bracket by either using the anchors provided in the kit or using the double sided tape.



### Step 5

Switch on the Shut-off valve. Make sure that there is no water dripping from the Tank valve or Shut-off valve. In case of water dripping close the shut off valve immediately

## Helpful hints.

If flow control valve on Handy Spray is dripping tighten small nut underneath flow control lever. Sometimes using Teflon sealing tape before screwing on the tank nut will ensure the best seal. For best performance replace the spray part of the kit every 12 months.

## Please Note.

Some of the Handy Spray kits have a compression nut directly connected to the flow valve which you can screw onto the shut-off valve.

Do not use a wrench to tighten the Tank nut and only use the wrench lightly to tighten the nut on the shutoff valve